


MANUAL MB-011




This tool is for pushing the small pieces out of the board. Also may be used for disassembly.


6




2




7




4




8



5



9



push the small pieces